

How-to Guide to Pressure Canning

Canning food at home is a great way to preserve fresh food for later use. The key is canning food properly and safely to prevent foodborne illness.

A pressure canner must be used to safely can low-acid foods. These foods include:

- Vegetables
- Vegetable mixtures
- · Red meats and wild game meats
- Poultry
- · Seafood and Fish

A pressure canner may be used to can some high-acid or acidified foods. These foods include:

- Tomatoes
- Some tomato products
- Apples
- Berries
- Cherries
- Fruit purees

- Grapefruit or oranges
- Peaches, apricots, or nectarines
- Pears
- Plums
- Rhubarb

Why Use a Pressure Canner?

Growth of the bacterium *Clostridium botulinum* in canned food may cause botulism — a deadly form of food poisoning. Botulinum spores are very hard to destroy at boiling-water temperatures; the higher the canner temperature, the more easily they are destroyed. Therefore, all low-acid foods must be processed at temperatures of 240° to 250°F, attainable with pressure canners operated at 10 to 15 pounds per square inch of pressure as measured by gauge (PSIG). The exact time depends on the kind of food being canned, the way it is packed into jars, and the size of jars.

Three serious errors in temperatures obtained in pressure canners occur because:

- 1. **Internal canner temperatures are lower at higher elevations.** To correct this error, increase pressure for your elevation of residence.
- 2. Air trapped in a canner lowers the temperature obtained at 5, 10, or 15 pounds of pressure and results in under processing. All pressure canners must be vented 10 minutes before adding the weight to properly pressurize the canner.
- 3. **An inaccurate dial gauge is used.** Check dial gauges

yearly for accuracy. If the gauge reads high or low by more than two pounds at 5, 10 or 15 pounds pressure, replace it. Many local Extension offices have equipment to test these brands of pressure gauges: Presto[®], National, Maid of Honor, and Magic Seal. We cannot test any other brands of canner gauges.

Recommended Pressure Canners for Low-Acid Foods

Today's pressure canner may have a weighted gauge or dial gauge, for indicating and regulating the pressure. Weighted gauges are designed to "jiggle" several times a minute or rock gently to maintain proper pressure. Read your manufacturer's directions to know how a particular weighted gauge should function. Dial gauge canners will usually have a counterweight or pressure regulator for sealing off the open vent pipe to pressurize the canner. This weight should not jiggle or rock at pressures below 15 PSIG. The dial gauge measures the pressure. One manufacturer makes a dual-gauge canner and must be used as a weighted gauge canner. Read the manufacturer's user manual for complete instructions and practice using your canner with just water to learn how it works with your cooktop.

As an alternative to stovetop canning, the Presto Precise® Digital Pressure Canner is an excellent option. This standalone electric appliance senses and responds to temperature to safely pressure can food. It can also be used as a water bath canner. It is important to follow the step-by-step directions with this appliance for safe operation and results.

Types of Pressure Canners NOT Recommended

USDA does not recommend canning in a small pressure cooker or pressure saucepan. The research for processing vegetable and meat products was conducted in pressure canners similar to today's 16-quart or larger pressure canners. Some brands of pressure canners are no longer made and may not be safe to use. It is also difficult to impossible to find replacement parts for discontinued canners.

Canning in electric multi-cookers with pressure canning or steam canning functions is not supported by the USDA. Pressure process directions have not been developed for these appliances, and the canner being used does matter.

Know Your Cooktop

With the advancement of kitchen technology, the smooth glass cooktop has brought some challenges for canning.


Follow the manufacturer's recommendations and consider these issues:

- 1. Some brands of pressure canners are NOT recommended to use on smooth cooktops because of style, size, and weight. Always follow the manufacturer recommendations for the stovetop and canner.
- 2. Excessive heat reflecting down on the surface can damage the cooktop. Examples are discoloration, burner damage, cracked glass tops, or metal fused to the glass top.
- 3. Many of these cooktops have automatic cut-offs on their burners when heat gets excessive. If the burner shuts off during processing, food can be under-processed.
- 4. Be sure the canner sits flat and is no more than oneinch larger in diameter than the burner being used for complete heat transfer.
- 5. If you have an induction cooktop, Presto® makes a dial gauge canner that is compatible with induction cooktops.


Steps for Successful Pressure Canning

Always read the instruction manual for your canner. Make sure the pressure canner is working properly before preparing food. Clean lid gaskets and other parts according to the manufacturer's directions; make sure all vent pipes are open. Center the canner over the burner. Your pressure canner can be damaged if the burner puts out too much heat. In general, do not use on an outdoor LP gas burner or gas range burner over 12,000 BTUs. Check your manufacturer's directions for more information about appropriate burners.


- 1. Put the rack and hot water into the canner. Use enough water so it is 2 to 3 inches deep in the canner. Longer processes require more water. Refer to canner directions for more information. Add ¼ cup vinegar to the water to help prevent hard water stains on jars and inside the canner.
- 2. Preheat water to 140°F for raw-packed foods and to 180°F for hot-packed foods.
- 3. Prepare food to be canned. Fill jars as directed for the type of food being canned. Apply lids and screw rings. Tighten rings fingertip tight.
- 4. Load filled jars onto the canner rack one jar at a time, using a jar lifter.
- 5. Fasten the canner lid securely. Leave the weight off the vent pipe or open the petcock.
- 6. Turn the heat setting to its highest position. Heat until the water boils and steam




7. Place the counterweight or weighted gauge on the vent pipe, or close the petcock to pressurize the canner.



describes, start timing the process. Use the recommended pressure for your elevation of residence. More information about adjusting processing for higher elevations is in What's



- 9. Regulate heat to maintain a steady pressure at, or slightly above, the correct gauge pressure. IMPORT-**ANT:** If the pressure goes below the recommended amount, bring the canner back
 - to pressure and restart the processing time.



- 11. Once depressurized, remove the weight or open the petcock. Wait 10 minutes; unfasten the lid and remove it carefully, pointing away from your face.
- 12. Remove jars with a jar lifter and place them on a towel or cooling rack, leaving at least 1-inch spaces between the jars during cooling. **Do**
 - not adjust or touch the lids or rings at this time. Let jars sit undisturbed at room temperature for 12 to 24 hours. Check lids for proper sealing.



Storing Your Canner

After canning season is done, clean and maintain your canner. Clean the vent and safety valve. To clean the vent, draw a clean string, narrow strip of cloth, or a pipe cleaner through the opening. Make sure the safety valve is free of debris and operates freely. Clean the valve by removing, if possible, and follow the manufacturer's instructions.



Check the rubber gasket for cracks or damage. If needed, new gaskets can be ordered from the canner manufacturer or found at stores where canning supplies are sold.

Before next canning season, have your dial gauge tested for accuracy by contacting your county or district extension agent. Do not immerse the gauge in water when cleaning.

The darkened surface on the inside of an aluminum canner can be cleaned by filling it above the darkened line with a mixture of 1 tablespoon cream of tartar or vinegar to each quart of water. Place the canner on the stove, heat water to a boil, and boil covered until the dark deposits disappear. Stubborn deposits may require the addition of more cream of tartar. Empty the canner and wash it with hot soapy water, rinse, and dry. (Hint: reduce hard water stains by adding ½ cup of white vinegar to the water in the canner while processing jars.)

Store the canner in a clean, dry location with crumpled clean paper towels inside the canner. This will help absorb moisture and odors. Place the lid upside down on the canner for ventilation. Never put the lid on the canner and seal it.

Sources:

National Center for Home Food Preservation, https://nchfp.uga.edu

USDA Complete Guide to Home Canning, 2015, Bulletin No. 539

National Presto Industries, Inc., https://www.gopresto.com/content/support/facs-resources

Prepared by: Varen Platration Fritancian Associate and Panid Personal Contar Coordinator hillahad@hau.edu
Karen Blakeslee, Extension Associate and Rapid Response Center Coordinator, kblakesl@ksu.edu
Brand names appearing in this publication are for product identification purposes only. No endorsement is intended, nor is criticism implied of similar products
not mentioned. Publications from Kansas State University are available at: bookstore.ksre.ksu.edu Date shown is that of publication or last revision. Contents of this publication may be freely reproduced for educational purposes. All other rights reserved. In each
case, credit Karen Blakeslee, <i>How-to Guide to Pressure Canning</i> , Kansas State University, November 2023. Kansas State University Agricultural Experiment Station and Cooperative Extension Service
MF3242 rev. K-State Research and Extension is an equal opportunity provider and employer. Issued in furtherance of Cooperative Extension Work, Acts of May 8 and June 30, 1914, in cooperation with
the U.S. Department of Agriculture, Director of K-State Research and Extension, Kansas State University, County Extension Councils, Extension Districts.